Wall Mounted RF AC CCT Controller

09.2836NCT.04765

Rotate the knob clockwise:

1. Increase light intensity from 1% to 100% (brightness mode).

2. Change color temperature from cold

white to warm white(dual color mode)

Product Data


FC CE PROHS 🕀 🌚

Important: Read All Instructions Prior to Installation

Function introduction





- 1. Decrease light intensity from 100% to
- 1%(brightness mode).
- 2. Change color temperature from warm white to cold white(dual color mode)



Click the knob to switch ON/OFF.Press and hold down to adjust brightness to 100%. Double click the knob to switch between dual color mode and brightness mode.







- Rotation sensitive
- Compatible with all universal series RF receivers, radio frequency: 869.5/434MHz
- Control CCT color
- Control 1 zone of RF receiver
- Safe and reliable full isolation design

Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

Operation

Pair with RF receivers:

Click "Learning Key" on RF receiver, or re-power on the receiver three times \rightarrow Revealed or click the knob \rightarrow LED lights connected with the \rightarrow The receiver is paired with RF receiver will flicker once the remote successfully.

How to delete the pairing:

Press and hold down "Learning Key" on the receiver for over 3 seconds until connected LED lights flicker twice, which means the pairing is deleted successfully.

Wiring diagram

